

#### PROPER USAGE

- Do not exceed weight limits of the exercise device.
- 2. If applicable, set safety stops to appropriate height.
- If applicable, adjust seat pads, leg pads, foot pads, range of motion adjustment, or any other type of adjustment mechanisms to a comfortable start position. Make certain that the adjusting mechanism is fully engaged to prevent unintentional movement and to avoid injury.
- 4. Sit on bench (if applicable) and get into appropriate position for exercise.
- Exercise using no more weight than you can safely lift and control.
- 6. In a controlled manner, perform exercise.
- Return weight to its fully-supported start position.

#### MAINTENANCE CHECKLIST

ACTION	FREQUENCY
Clean Upholstery *	Daily
Inspect Cables	Daily
Clean Guide Rods	Monthly
Inspect Hardware	Monthly
Inspect Frame	Bi-Annually
Clean Machine	As Needed
Clean Grips *	As Needed
Lubricate Guide Rods †	As Needed

- \* Upholstery & Grips should be cleaned with a mild soap and water or a non-ammonia based cleaner.
- † Guide rods should be lubricated with Teflon based lubricant. Apply the lubricant to a cotton cloth and then apply up and down the guide rods.

### **PRODUCT SPECIFICATIONS**

TECH SPECS		
Maximum User Weight	182 kg / 400 lbs.	
Maximum Training Weight	363 kg / 800 lbs.	
Product Weight	308 kg / 673 lbs.	
Overall Dimensions (L x W x H)*	235.9 x 218.1 x 236.2 cm / 92.9" x 85.9" x 93"	
Weight Horn Diameter (Weight Plate Storage)	47.63 mm / 1.875"	

<sup>\*</sup> Ensure a minimum clearance width of 914 mm / 36" for access to and passage around MATRIX strength equipment.

#### WARRANTY

Valid in USA only		
Frame (not coatings) *	10 years	
Weight stacks	5 years	
Pulleys	5 years	
Pivot bearings	5 years	
Any items not specified	3 years	
Labor (excludes upholstery/cables/grips)	3 years	
Upholstery/cables/grips/springs	1 year	

<sup>\*</sup> Frame is defined as the welded metal base of the unit and does not include removable parts.

Available without integrated foldaway spotter stands (VY-D691N)

© 2014 Johnson Health Tech. All Rights Reserved.



#### IMPORTANT SAFETY INFORMATION

It is the sole responsibility of the purchaser of MATRIX products to instruct all individuals, whether they are the end user or supervising personnel on proper usage of the equipment.

It is recommended that all users of MATRIX exercise equipment be informed of the following information prior to its use.

Do not use any equipment in any way other than designed or intended by the manufacturer. It is imperative that MATRIX equipment be used properly to avoid injury.

#### INSTALLATION

- STABLE AND LEVEL SURFACE: MATRIX exercise equipment must be installed on a stable base and properly leveled.
- SECURING EQUIPMENT: Manufacturer recommends that all stationary MATRIX strength equipment be secured to the floor to stabilize equipment and eliminate rocking or tipping over. This must be performed by a licensed contractor.

All anchor points must be able to withstand 750 lbs. (3.3 kN) pull-out force.

#### **MAINTENANCE**

- DO NOT use any equipment that is damaged and or has worn or broken parts. Use only replacement parts supplied by your country's local MATRIX dealer.
- MAINTAIN LABELS AND NAMEPLATES: Do not remove labels for any reason. They
  contain important information. If unreadable or missing, contact your MATRIX dealer
  for a replacement.
- MAINTAIN ALL EQUIPMENT: Preventative maintenance is the key to smooth operating equipment as well as keeping your liability to a minimum. Equipment needs to be inspected at regular intervals.
- Ensure that any person(s) making adjustments or performing maintenance or repair of any kind is qualified to do so. MATRIX dealers will provide service and maintenance training at our corporate facility upon request.

#### **ADDITIONAL NOTES**

This equipment should only be used in supervised areas where access and control is specifically regulated by the owner. It is up to the owner to determine who is allowed access to this training equipment. The owner should consider a user's: degree of reliability, age, experience, etc.

This training equipment meets industry standards for stability when used for its intended purpose in accordance with the instructions provided by the manufacturer.

This training equipment is in compliance with EN 957-1 and the relevant portions of EN 957-2 and EN 957-4.

# **AWARNING**

DEATH OR SERIOUS INJURY CAN OCCUR ON THIS EQUIPMENT. FOLLOW THESE PRECAUTIONS TO AVOID INJURY!

- NEVER allow children on strength training equipment. Teenagers must be supervised at all times while using this equipment.
- All warnings and instructions should be read and proper instruction obtained prior to use. Use this equipment for its intended purpose ONLY.
- 3. Inspect the machine before use. DO NOT use machine if it appears damaged or inoperable.
- 4. Unless this equipment is secured to the floor by a licensed contractor, NEVER allow resistance straps, ropes or other means to be attached to this equipment, as this may result in serious injury. NEVER use this equipment for support during stretching, as this may result in serious injury.
- ALWAYS use a spotter.
- Do not exceed the weight capacity of this equipment.
- Balance the weight applied to this equipment and/or any barbell. Where applicable, use retention devices to retain weight discs.
- Injuries to health may result from incorrect or excessive training. Cease exercise if you feel faint or dizzy.
   Obtain a medical exam before beginning an exercise program.
- 9. Keep body, hair, clothing, and fitness accessories free and clear of all moving parts.
- Manufacturer recommends that all equipment be secured to the floor to stabilize and eliminate rocking or tipping over. Use a licensed contractor.
- 11. DO NOT REMOVE THIS LABEL. REPLACE IF DAMAGED OR ILLEGIBLE.
- 12. For Smith Machines: Visually ensure lifting bar catch rods are fully engaged and seated in the hooks before releasing the load and exiting the machine.
- 13. For Smith Machines: ALWAYS set both adjustable stops to the same height when using this machine.
- 14. Adjustable safety stops, if present, must be used at all times.
- 15. For equipment with adjustable stops: PROPER adjustable stop height depends on the exercise performed. Adjust as follows:
  - · Remove weight from lifting bar.
  - For squats, perform the exercise and determine the lowest comfortable position of the bar that ensures
    no spinal compression. For other exercises, perform the movement and determine the lowest point of
    bar travel that is comfortable without the bar contacting your body.
  - Position both stop catches to stop the bar at this point. Ensure that they are completely seated on the stop rods or catch plate.
  - · Load weights onto the lifting bar and carefully perform the exercise.
- 16. When adjusting any adjustable mechanism (seat position, pad location, range of motion limiter, pulley carriage, or any other type of adjuster), make certain that the adjusting pin is fully engaged in the hole to avoid injury.
- 17. Keep hands and feet clear at all times from moving parts to avoid injury.

## MATRIX®


#### VY-D691 FRAME ASSEMBLY


Note: If your rack is not equipped with spotter stands proceed to step 2.


- Using (2) 3/8-16 x 2 3/4" bolts, (4) 3/8" washers and (2) 3/8" jam nuts attach the spotter stand support legs to lower base support. Do not fully tighten bolts until step 11.
- Place lower base support and bases where the machine is to be used. Using (4) 3/8-16 x 4 1/4" bolts, (8) 3/8" washers and (4) 3/8" nuts attach the base support to the bases and torque all bolts to 30 ft lbs.
- 3. Attach each upright to the base using (16) 3/8-16 x 2 3/4" bolts, (32) 3/8" washers and (16) 3/8" jam nuts. Do not fully tighten bolts.
- 4. Weight storage, lower: Using (8) 3/8-16 x 2 3/4" bolts, (16) 3/8" washers and (8) 3/8" jam nuts, attach the bottom of the weight stor-age to the bases. Do not fully tighten bolts.
- 5. **Upright support:** Using (16) 3/8-16 x 4" bolts, (32) 3/8" washers and (16) 3/8" nuts, attach the upright support to the top of the uprights. Do not fully tighten bolts.
- 6. Weight storage top: Using (4) 3/8-16 x 3" bolts, (8) 3/8" washers, and (4) 3/8" nuts, attach the top of the weight storage to the upright support. Do not fully tighten bolts.
- 7. Chin Bar: Using (16) 3/8-16 x 4" bolts, (32) 3/8" washers and (16) 3/8-16 nuts, attach the chin bars between the tops of the uprights. Do not fully tighten bolts.


Note: If your rack is not equipped with spotter stands proceed to step 8. If your rack is equipped with spotter stands proceed to steps 9 thru 11.

- 8. Tighten bolts: Starting with the bottom of the uprights and working up to the top of the machine tighten all bolts to 30 ft.
- Spotter stands: Using (4) 3/8-16 x 5 1/2" bolts, (2) 3/8-16 x 6" bolts, (12) 3/8" washers and (6) 3/8" nuts, attach the spotter stands between the upright and weight storage. Do not fully tighten bolts.
- 10. Spotter stands: Using (2) 3/8-16 x 6" bolts, (4) 3/8" washers and (2) 3/8" nuts, attach the spotter stands to the spotter stand support legs. Do not fully tighten bolts.
- 11. Tighten bolts: Starting with the bottom of the uprights and working up to the top of the machine tighten all bolts to 30 ft lbs.









## MATRIX ®

## **VY-D691 FRAME ASSEMBLY**

